



2650-1865-77

1955-56 CHEVY CAR BILLET ALUMINUM DASH INSERT

Model 7033

1. The bezel that this insert installs into will need to be removed from your vehicle.
2. Insert the high beam indicator light into the small hole at the bottom of the billet insert. You will not have room to install this light once the billet insert has been attached to the stock bezel.
3. Place the stock bezel face down & lay the billet aluminum dash insert into it.
4. Place the gauges into the desired locations.
5. Place the back panel over the gauges & secure to the front panel using the six provided 10-32 x 3/8" screws. Do not fully tighten until you are satisfied with the position of your gauges. Adjusting the gauges while fully tightened may damage the gauges.
6. Secure the billet insert to the stock bezel using the five provided brackets & 8-32 x 3/8" machine screws.
7. Install the 2 turn signal lights. The eraser end of a pencil works well to push these in.
8. Install the bezel into your vehicle.
9. Wire the gauges (refer to instructions provided by the gauge manufacturer).

866-248-6356

www.autometer.com

2650-1865-77 12/7/15



2650-1864-77

1955-56 CHEVY CAR BILLET ALUMINUM DASH INSERT

Model 7033

1. The bezel that this insert installs into will need to be removed from your vehicle.
2. Insert the high beam indicator light into the small hole at the bottom of the billet insert. You will not have room to install this light once the billet insert has been attached to the stock bezel.
3. Place the stock bezel face down & lay the billet aluminum dash insert into it.
4. Place the gauges into the desired locations.
5. Place the back panel over the gauges & secure to the front panel using the six provided 10-32 x 3/8" screws. Do not fully tighten until you are satisfied with the position of your gauges. Adjusting the gauges while fully tightened may damage the gauges.
6. Secure the billet insert to the stock bezel using the five provided brackets & 8-32 x 3/8" machine screws.
7. Install the 2 turn signal lights. The eraser end of a pencil works well to push these in.
8. Install the bezel into your vehicle.
9. Wire the gauges (refer to instructions provided by the gauge manufacturer).

866-248-6356

www.autometer.com

2650-1865-77 12/7/15